




(1)



(2)



(3)



(4)



Instructions for #55324 Everlasting Christmas Trees, With Adaptor

FEATURES:

- On/off switch with volume control.
- The big sign turns on the dome.
- Buckets of parts move into the assembly area on conveyor belt.
- Sound track in English only.

OPERATING INSTRUCTIONS:

- Place the unit on flat, level surface.
- Insert the big sign (included) on top of the dome on Diagram 1.
- Hang the basket of colorful lights (included) on hook on left side of the unit on Diagram 2.
- Insert the sign board (included) at the front on right side of the unit on Diagram 3.
- Operate by using the adaptor included. Insert the jack into the reception socket (A) at the back of the unit on Diagram 4. Plug the adaptor into a household electrical outlet.
- Turn Power Switch/Volume Control (B) extending from rear of the unit to "—" position until "click" sound is heard and the volume is at desired level on Diagram 5.
- Background sounds/music will be heard. Animation will begin and lights will illuminate the unit.


POWER:

- DC 4.5 V

CAUTIONS:

- This is not a toy, therefore not suitable for children. Keep out of reach of children.
- Do not turn on the unit until accessories have been properly placed.
- When you move the unit, take away the accessories to protect them from being dropped off.
- Suggest using the adaptor provided.
- This power unit is intended to be correctly orientated in a vertical or floor mount position.

The symbol on the product and/or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU. For more information, please contact the local authority or your retailer where you purchased the product.



(5)

- Christmas tree rotates on rooftop on the right.
- Snowflakes rotate inside the snow globe at the flocking station.
- Lights in multi colors are on along the roof eave of the main building.

PRINTED IN CHINA



Directives – Article n° 55324 Arbres de Noël éternels, avec adaptateur

CARACTÉRISTIQUES :

- Interrupteur marche/arrêt avec réglage du volume.
- La grande enseigne sur le dôme tourne.
- Les caisses de pièces détachées entrent dans la zone d'assemblage par le tapis roulant.
- Bande sonore en anglais seulement.

NOTICE D'EMPLOI :

- Déposez l'article sur une surface plane et de niveau.
- Insérer la grande enseigne en haut du dôme (inclus), tel que vu sur le Diagramme 1.
- Suspender le panier de lumières colorées au crochet sur la gauche du module (inclus), tel que vu sur le Diagramme 2.
- Insérer l'enseigne à l'avant sur la droite du module (inclus), tel que vu sur le Diagramme 3.
- Pour mettre l'article sous tension, employez l'adaptateur inclus à cet effet. Branchez le jack dans la prise d'alimentation (A) située à l'arrière de l'article, tel que vu sur le Diagramme 4. Branchez l'adaptateur dans une prise murale domestique.
- Déplacez l'interrupteur d'alimentation et de réglage du volume (B), situé à l'arrière de l'article, à la position "—", jusqu'à ce que vous entendiez un léger déclic et que le volume atteigne l'intensité désirée, tel que vu sur le Diagramme 5.
- Vous entendez maintenant un fond sonore musical et divers sons. L'animation commence et des lumières illuminent l'article.

ALIMENTATION :

- C. C. 4.5 V

MISES EN GARDE :

- Ceci n'est pas un jouet, et ne convient donc pas aux enfants. Conserver hors de portée des enfants.
- Ne mettez pas l'article sous tension avant que les accessoires n'aient été correctement mis en place.
- Au moment de déplacer l'unité, retirez les accessoires afin de ne pas les échapper.
- N'employez que l'adaptateur inclus avec l'article.
- Ce bloc-moteur est destiné à être correctement orienté en position verticale, ou à plat, sur le sol.

The symbol on the product and the instructions signifies that the electrical and electronic equipment must be eliminated at the end of its life cycle, and this, separately from household waste. There are separate systems of collection for recycling in Europe. For further information, please communicate with the authorities local or the dealer where the product has been purchased.

IMPRIMÉ EN CHINE



Instrucciones para #55324 Arboles de Navidad Everlasting, con adaptador

CARACTERÍSTICAS :

- Interruptor encendido/apagado con control de volumen.
- El letrero de "Big and small" enciende la cúpula.
- Los cubos con piezas se mueven hacia el área de armado en la cinta transportadora.
- Sonido únicamente en inglés.

INSTRUCCIONES DE OPERACIÓN :

- Coloque la unidad sobre una superficie plana y nivelada.
- Inserte el letrero de "Big and small" arriba de la cúpula (incluido), tal como se muestra en la Diagrama 1.
- Cuelgue la canasta con luces de colores en el gancho de la izquierda de la unidad (incluido), tal como se muestra en la Diagrama 2.
- Inserte el letrero en la parte derecha del frente (incluido), tal como se muestra en la Diagrama 3.
- Opere con el uso del adaptador incluido. Inserte el enchufe en el enchufe de entrada (A) detrás de la unidad (Diagrama 4). Conecte el adaptador al tomacorriente.
- Gire el interruptor de alimentación/control de volumen (B) que se extiende desde la parte trasera de la unidad a la posición "—", hasta que se escuche "clic" y el volumen estará en el nivel deseado (Diagrama 5).
- Se escucha música y sonidos de fondo. Las animaciones comenzarán y las luces iluminarán la unidad.

ENERGÍA :

- CC de 4.5 V

PRECAUCIONES :

- Esto no es un juguete, por lo que no es adecuado para niños. Mantener fuera del alcance de los niños.
- Encienda la unidad luego de haber colocado los accesorios de manera adecuada.
- Cuando desplace la unidad, retire los accesorios para evitar que se caigan.
- Se recomienda utilizar el adaptador suministrado.
- Esta unidad de alimentación debería estar correctamente orientada en posición vertical o de montaje en el piso.

The symbol printed on the product and/or in the instructions signifies that the electrical and electronic equipment must be discarded at the end of its useful life in a place separate from the general household waste. In the European Union there are systems of collection for recycling separately. For further information, please contact the local authorities or the dealer where you purchased the product.

IMPRESO EN CHINA

55324.v01